

Fire Tischkamin

Diese Gebrauchsinformation ist vor dem Benutzen des Philippi Tischkamin Fire sorgfältig zu lesen und für die weitere Verwendung aufzubewahren.

ACHTUNG:

- Den Tischkamin nur entzünden, wenn dieser einen horizontalen und sicheren Stand hat. Den entzündeten Kamin nicht bewegen.
- Der Kamin darf nicht zur Raumheizung genutzt werden.
- Stellen Sie sicher, dass keine brennbaren Materialien im Umkreis von 80 cm um den Kamin herum sind.
- Legen Sie niemals etwas oben auf den Kamin drauf.
- Nicht in Reichweite von Kindern aufbewahren oder verwenden.
- Lassen Sie den Kamin niemals unbeaufsichtigt brennen.
- Beachten Sie die allgemeinen Vorsichtsmaßnahmen im Umgang mit offenem Feuer.


Bedienungsanleitung

Verwenden Sie nur hochwertige duftfreie Qualitäts-Paraffin-Lampenöle mit einem Flammpunkt von mindestens 70°C.

1. Packen Sie den Kamin vollständig aus.

2. Befüllen Sie den Tischkamin mit Lampenöl.

3. Dazu entfernen die den großen Dochthalter in der Mitte des Kamins mit Hilfe der mitgelieferten Pinzette.



4. Füllen Sie das Lampenöl mit Hilfe des mitgelieferten Trichters in den Tank. Die maximale Füllmenge des Behälters beträgt 600 ml und darf nicht überschritten werden.

5. Setzen Sie den Dochthalter wieder ein und verschrauben Sie ihn ordnungsgemäß. Überprüfen Sie den festen Sitz des Dochthalters. Justieren Sie den Docht so, dass maximal 1mm aus dem Loch des Dochthalters herausragt.

Sollte sich nach dem Befüllen Lampenöl auf der Bodenplatte befinden, nehmen Sie dies vor Benutzung unbedingt auf. Der Tischkamin darf vorher nicht entzündet werden - Brandgefahr!

6. Legen Sie dann die Steine zwischen die Dochte und zünden Sie diese an.

Regulierung der Flammenhöhe:

Die Flammen werden höher, je weiter der Docht aus der Halterung herausgezogen wird.

Sind die Flammen zu groß, stecken Sie die Dochte etwas weiter hinein.

Sind die Flammen zu klein ziehen Sie die Dochte etwas weiter heraus. Verwenden Sie für die Regulierung die mitgelieferte Pinzette.

ACHTUNG: Justieren Sie den Docht so dass er maximal 1mm aus dem Loch des Dochthalters herausragt.

Reinigung:

Sie können den Kamin bedenkenlos mit Spülmittel abwaschen.

Verwendung Drinnen/Draußen:

Sie können den Kamin drinnen und draußen verwenden. Bitte verwenden Sie immer eine feuerfeste Unterlage. Verwendung draußen: Achten Sie darauf, dass kein Regenwasser in den Kamin läuft. Wenn sich dieser mit dem Lampenöl vermischt, brennt der Kamin nicht mehr.

Hitzeentwicklung:

Der Kamin ist aus Metall gebaut, welches Hitze gut leitet. Wenn der Kamin brennt, können der Tank, die Steine und die Glasscheiben heiß werden, überprüfen Sie dieses bevor sie ihn anfassen.

Baumwollummantelter Glasfaserdocht mit 4 mm Durchmesser, es dürfen nur Dochte dieser Bauart mit einer Länge von > 75 mm verwendet werden.

Wir wünschen Ihnen viele (er)leuchtende Stunden mit Ihrem Tischkamin, Ihr Philippi Team.

ACHTUNG!

Öllampen und Lampenöl unter Verschluss und für Kinder unzugänglich aufbewahren. Produktinformationen vor Gebrauch sorgfältig lesen.



Diese Produktinformation ist vor dem Gebrauch dieses Philippi Produktes sorgfältig zu lesen und für die weitere Verwendung aufzubewahren.

BRENNENDE ÖLLAMPEN NICHT UNBEAUF SICHTIGT LASSEN.

Warnung:

Dieses Produkt enthält im gebrauchsfertigen Zustand Lampenöl und ist für Kinder unzugänglich aufzubewahren, ebenso wie der mitgelieferte Trichter mit Verlängerung und die Vorratsbehälter Lampenöl.

Warnung:

Bei kleinen Kindern kann bereits ein Schluck Lampenöl - oder sogar das Saugen am Docht - zu lebensbedrohlichen Lungenschäden führen.

Warnung:

Beim Verschlucken von Lampenöl kein Erbrechen auslösen und niemals Wasser verabreichen. Sofort einen Arzt suchen oder eine Vergiftungsinformationszentrale kontaktieren und diese Warnhinweise zeigen.

Achtung:

Dochte dürfen nur 1 mm aus dem Loch der Dochthalterung herausragen. Die maximale Füllmenge des Behälters von 600 ml darf nicht überschritten werden. Die Öllampe nur entzünden, wenn sie einen horizontalen und sicheren Stand hat. Die entzündete Öllampe nicht bewegen. In der Seite des Tanks bendet sich ein kleines Luftloch. Die befüllte Öllampe nicht neigen, da sonst Öl austreten könnte.

ACHTUNG!

Öllampen und Lampenöl unter Verschluss und für Kinder unzugänglich aufbewahren. Produktinformationen vor Gebrauch sorgfältig lesen.



Fire Table Fireplace

Please read this instruction sheet carefully before taking the Philippi table fireside Fire into use and retain this information for further reference/usage.


ATTENTION:

- Only ignite the oil lamp if it has been placed on a fireproof base and it stands level and secure; do not move the oil lamp after ignition.
- The fireplace may not be used for heating purposes.
- Make sure that no flammable material is found within a 80 cm radius of the oil lamp.
- Never lay anything on top of the oil lamp.
- Do not use or store the fireplace within reach of children.
- Never leave the fireplace burning unattended.
- Please observe the general precautionary measures when dealing with open fire.

Instruction sheet

Only use high-quality paraffin lamp oil with a flashpoint of minimum 70°C. By no means should you use any type of fragrance oil or essences.

1. Unpack the fireplace completely.
2. Fill the oil lamp with lamp oil.
3. To fill the table fireside with lamp oil; take out the big wick holder in the middle with the help of the forceps.



4. Take the funnel, slide the tube of the funnel into the opening and pour the lamp oil into the funnel. Fill the tank with a maximum of 600 ml of oil lamp only. Under no circumstances, may the maximum filling capacity be exceeded!
5. Then insert the wick holder with the lolling wick into the hole on the base. Adjust the wicks, so that they poke out of the holes of the wick holders maximum 1 mm.

Should there be any oil on the base please absorb it. Do not light the wicks with oil on the base - fire hazard!

6. Place the stones between the wick holders. When all stones are in place, light the wicks.

Regulating the height of the flames:

The longer the wick is, the higher the flames will burn. Should the flame be too high, minimally push the unlit wick back into the holder.

Should the flame be too low, carefully pull the unlit wick out a bit. Please use the forceps for this.

WARNING: Adjust the wicks, so that they poke out of the holes of the wick holders maximum 1 mm!

Cleaning:

The table fireplace can easily be cleaned with normal dishwashing liquid. Attention: The table fireplace is NOT dishwasher compatible.

Interior and Exterior Use:

You can use the table fireplace both inside and outside. Please make sure that you use a hot mat when placing the table fireplace on any furniture.

Exterior use: Please make sure that no rainwater runs into the table fireplace. The table fireplace will not burn, should water mix with the lamp oil.

Development of heat:

The table fireplace is made of metal that conducts heat well. Once the table fireplace is set afire, the tank, stones and the glass can become hot. Please be extremely cautious when touching or picking up the table fireplace to avoid burns.

Cotton coated fibre glass wicks with a diameter of 4mm. It is only allowed to us wicks of this kind with length shorter then 75mm.

We wish you (de)lightful hours with your new FIRE Table Fireplace! Your Philippi-Team!

ATTENTION!

Oil lamps and lamp oil must be kept sealed and out of reach of children. Read the product information carefully before taking the oil lamp into use.



Please read this product information sheet carefully before taking the Philippi table fireside Fire into use and retain this information for further reference/usage.

NEVER LEAVE THE BURNING OIL LAMP UNATTENDED.

WARNING: In ready for use condition, this product contains lamp oil and must be kept out of reach of children! This also applies for the funnel and its extension as well as to the container for storage of lamp oil.

WARNING: For small children already one zip of lamp oil - or only sucking from the wick - may cause life-threatening lung injuries.

WARNING: If lamp oil is swallowed do not vomit. Immediately contact your physician or nearest poison information center and show this warning notice/ product information.

ATTENTION: The wicks are only allowed to stick out of the hole of the holder 1 mm. Cotten coated fibre glass wicks with 4 mm diameter; it is only allowed to use the same wick type with a length smaller then 75 mm for the use of this oil lamp. Under no circumstances, may the maximum filling capacity of 600 ml be exceeded. Only ignite the table fireplace if it has been placed on a fireproof base and it stands level and secure; do not move the fireplace after ignition. At the side of the tank is a small air hole.
Do not incline the oil lamp as otherwise some oil might leak out of the tank.

ATTENTION!

Oil lamps and lamp oil must be kept sealed and out of reach of children. Read the product information carefully before taking the oil lamp into use.

